

Revised March 2007

PRODUCT INFORMATION

FC-4260-01

SOLVER LINE 4260 - EASY WASH ACRYLIC LOW SHEEN

DESCRIPTION:

A washable, low sheen interior water-based acrylic wall finish specially formulated for easy application, high covering power and minimal spatter.

APPROVED TO

Australian Paint Approval Scheme Specification APAS 0260/3, Australian Standard AS3730.3.

USE ON:

Walls in commercial buildings and homes, including areas such as rumpus rooms, dining rooms, children's and family rooms, etc. DO NOT use for any purpose other than as specified in our literature.

COVERAGE:

Approximately 16 square metres per litre on smooth or sealed surfaces. On porous or rough surfaces, the spreading rate may drop to 10 square metres per litre for the first coat.

SURFACE PREPARATION:

NEW UNPAINTED SURFACES:

Ensure that all new surfaces are clean and free from dirt, grease, dust, or loose or friable matter. Coat ferrous nail heads with SOLVER Line 4129 Wall-Sealer to avoid rust spotting. Fill nail holes, cracks, etc. with appropriate patching material.

Paper-Faced Plaster Board:

Lightly sand joints and patching. Completely remove dust. Apply 1 coat of SOLVER Line 4245 Easy Wash Acrylic Undercoat-Sealer.

Brick, Masonry, Plaster, Fibrous-Cement, etc.:

Allow surfaces to cure and dry for at least 6 weeks. Allow 12 weeks for cast concrete surfaces. Clean down thoroughly. Apply 1 coat of SOLVER Line 4245 Easy Wash Acrylic Undercoat-Sealer. For Plaster, apply one coat of SOLVER Line 4129 Wall-Sealer as the first coat. For Plasterglass sheeting use SOLVER Line 4334 Plaster Glass Sealer as the first coat.

Interior Timber Surfaces:

Sand and dust down. Fill nail holes and cracks with appropriate patching materials. Sand lightly and dust off. Apply 1 coat of SOLVER Line 4668 Weatherflex Acrylic Timber Primer.

Interior Metal Surfaces (Zincalume, Zincanneal, Galvanized Steel):

Degrease these surfaces with SOLVER Line 4510 Solprep Degreaser. Apply 1 coat of SOLVER Line 4311 Maxi PSU Primer-Sealer-Undercoat.

PREVIOUSLY PAINTED SURFACES:

Ensure that surfaces are clean and free from dirt, grease, dust, or loose or friable matter. Remove loose and flaking paint and sand smooth. Gloss or semi-gloss surfaces must be completely dulled by sanding. Remove sanding dust. Spot prime bare areas as recommended for new areas above. When painting surfaces which have been previously painted with a flat or low sheen finish, no further preparatory coats are required. However if the surface has been previously painted with a gloss or semi-gloss enamel, or if the surface has been patched etc., a full coat of SOLVER Line 4245 Easy Wash Acrylic Undercoat-Sealer should be applied. Chalky surfaces such as Kalsomine must be washed and rubbed down to a sound surface. On areas where it is not possible to completely remove these materials apply SOLVER Line 4104 Surface Conditioner, and allow to dry for 48 hours.

STAIN SEALING:

Seal with SOLVER Line 4747 Quick Drying Multi Block Stain Sealer (Solvent based).

FUNGUS INFECTED AREAS:

Treat the surface with SOLVER Line 4651 Sterilizing Wall-Wash. If abnormal conditions are expected, SOLVER Line 4651 Anti-Fungus Additive may be added to the paint for extra protection. For normal conditions this addition will not be necessary.

STIRRING:

Mix contents thoroughly with a broad flat paddle reaching to the bottom of the can.

THINNING:

Not usually required. However, in hot or windy conditions or where painting very absorbent surfaces, add 50 ml. of SOLVER Line 4328 Hot Weather Thinners per 1 litre of paint. Use direct from can for all other conditions.

APPLICATION:

Apply 2 full even coats by brush, roller or airless spray. Use a medium nap (12mm pile) synthetic roller on smooth and semi-smooth surfaces. Use a longer nap (20mm pile) roller on rough surfaces, e.g., Besser Block. Use a 13 or 15 thou. tip for airless spray. Dip brushes or rollers in water before use and to keep them working freely, rinse occasionally in clean water.

DRYING TIME:

When temperature is around 25°C:

DRY TO TOUCH : 30 minutes

RECOAT : 2 hours.

Under cooler or humid conditions, allow longer times.

AVOID PAINTING WHEN EITHER THE SUBSTRATE OR AIR TEMPERATURE IS BELOW 12°C (or is likely to go below before paint can dry thoroughly). Allow up to 7 days for full film cure.

CLEAN UP:

Clean up with water. For best care of equipment use SOLVER Line 4331 Brush & Roller Cleaner to complete the clean up.

CARE OF PAINTWORK:

Allow 48 hours drying before exposing finish to light steam and condensation. Allow the paint to cure for at least 7 days before attempting to remove stains and scuff marks. Care must be taken to avoid rubbing and "polishing" of the finish when removing marks, which can cause patchiness. Therefore, when necessary, wash carefully using a soft sponge with warm soapy water. Do not use strong household cleaning agents as damage to the paint may result. Some strongly coloured stains may be difficult to completely remove. On hard wearing surfaces, such as furniture and kitchen cupboards, etc., or walls and ceilings subject to extreme moisture and condensation, use SOLVER Line 4198 Satin Enamel or SOLVER Line 4171 High Gloss Enamel.

COLOURS:

White and pastel colours as per SOLVER Colour Selector.

SIZES	20 Ltr	10 Ltr	6 Ltr	4 Ltr	2 Ltr	1 Ltr
White			✓	✓		

CAUTION:

PROVIDE ADEQUATE VENTILATION DURING USE.

FOR FURTHER SAFETY INFORMATION REFER TO MATERIAL SAFETY DATA SHEET OVERLEAF AND ALSO PRODUCT INFORMATION SHEET SS-100.

Keep out of reach of children

CHANGES SINCE LAST ISSUE:

Addition of Australian Standard.